

# More Precision

eddyNCDT 3060 // High-performance inductive displacement measuring system



# eddyNCDT 3060



- Wide range of applications with more than 400 sensor models
- Combination of resolution, linearity and temperature stability sets new standards
- Industrial suitability due to robust system design
- Easy integration with modern fieldbus connection and smart signal processing
- Maximum ease of use and intuitive configuration via web interface

#### Inductive displacement measurement based on eddy currents

Non-contact, inductive displacement sensors from Micro-Epsilon operate according to the eddy current measuring principle. Unlike conventional, inductive displacement sensors, they measure position, displacement and distance with high accuracy, bandwidth and temperature stability on ferromagnetic and non-ferromagnetic materials. Due to their immunity to oil, dirt, pressure and temperature, these inductive eddy current sensors are primarily used in industrial environments.

#### Performance and universality for industrial use

The eddyNCDT 3060 is a new, powerful eddy current measuring system for fast, high precision displacement measurements. The system comprises a compact controller, a sensor and an integrated cable and is factory-calibrated for either ferromagnetic or non-ferromagnetic materials. With more than 400 compatible sensor models, ease of use and smart signal processing, the eddyNCDT 3060 defines a new performance class in inductive displacement measurement.

## Ideal for integration into plant and machinery

As sensor and controller are temperature-compensated, a high measurement accuracy can be achieved even in fluctuating temperatures. The sensors are designed for ambient temperatures up to a maximum of +200°C and an ambient pressure up to 20 bar. The compact controller design as well as the fieldbus connection make the measuring system ideal for integration into plant and machinery.

#### New benchmark in controller technology


The industrial-grade M12 Ethernet interface enables a modern fieldbus connection. Configurable analog outputs enable to output the measured values as voltage or current. When connecting a PC via the Ethernet interface, a modern web interface can be accessed without any further installation and enables the software setting of sensor and controller.

The DT3061 controller provides enhanced features such as 5-point calibration, setting of switching and temperature outputs, as well as storage of multiple characteristic curves. If two or more systems operate next to one another, there is no need for synchronization. For operating several systems, a new frequency separation is provided, which enables to operate these systems in parallel without influencing one another.

Faahuraa	Controller type	
Features	DT3060	DT3061
Active temperature compensation for sensor and controller	✓	✓
Frequency separation (LF & HF)	$\checkmark$	$\checkmark$
Industrial Ethernet interface	$\checkmark$	$\checkmark$
Intuitive web interface	✓	✓
Multipoint calibration regardless of the distance (up to 3 points)	✓	✓
Scalable measuring range via analog output (teach function)	$\checkmark$	✓
Scalable analog output	$\checkmark$	$\checkmark$
Switching and temperature outputs	-	✓
5-point calibration	-	✓
Storage of multiple characteristic curves	-	✓

Model		DT3060	DT3061	
	up to 20Hz	≤0.002	% FSO	
Resolution 1)	up to 5kHz	≤0.005% FSO		
	up to 20kHz	≤0.019	% FSO	
Linearity 3-	ooint linearization	≤0.2%	6 FSO	
deviation 5-	ooint linearization	-	≤0.1% FSO	
Bandwidth (-3 dB)		20 kHz / 5 kHz / 20 Hz (selectable)		
Temperature compensation range	sensor	10°C	. 180°C	
	controller	10°C	50°C	
Temperature stability (MMR)	sensor	≤0.015 %	FSO / °C	
	controller	≤0.015 %	FSO / °C	
Ambient temperature	sensor	-20°C	+180°C	
	controller	0°C	+50°C	
Output (configurable)	analog	voltage (0 V 10 V), c	urrent (4 mA 20 mA)	
Output (configurable)	digital	Industrial Ethernet (socket	with M12 thread); 50kSa/s	
Power supply		12V 32V		
Weight		approx. 230g		
Synchronization		no sync - LF & HF variants		
Protection class (controller)		IP67 (when connected)		

FSO = full scale output MMR = midrange 1) RMS noise relates to midrange



# 8-pin controller connector, pin side view


Pin	Color	Description
1	white	U_displacement
2	brown	+24V
3	green	U_temp_sensor
4	yellow	U_temp_electr
5	gray	GND_temp_SW
6	pink	GND_displacement
7	blue	GND_power
8	red	I_displacement



## Sensors








Sensor type		ES-U1	ES-S2	ES-U3	ES-S4
Design		unshielded, cylindrical	shielded, cylindrical	unshielded, cylindrical	shielded, cylindrical
Measuring range (nominal)		1mm	2mm	3mm	4mm
Offset distance		0.1mm	0.2mm	0.3mm	0.4mm
Linearity deviation 1)	3-point linearization	. ≤2μm	≤4µm	≤6µm	≤8µm
	5-point linearization	. ≤1μm	≤2µm	≤3µm	≤4µm
Resolution 1) 2) 3)		≤0.02µm	≤0.04µm	≤0.06µm	≤0.08µm
Temperature stability 1) 2)		≤0.15µm/°C	≤0.3µm/°C	≤0.45µm/°C	≤0.6µm/°C
Temperature range	operation	-20°C +180°C	-20°C +200°C	-20°C +200°C	-20°C +200°C
Cable		integrated, axial	integrated, axial	integrated, axial	integrated, axial
Pressure resistance	fron	20 bar	20 bar	20 bar	20 bar
riessule lesistalice	e, static real	5 bar	5 bar	5 bar	5 bar
Vibration / shock 4)		15g / 30g	15g / 30g	15g / 30g	15g / 30g
Protection class	sensor	IP68	IP68	IP68	IP68
	plug-in connector, matec	IP68	IP68	IP68	IP68
Weight 5)		2.4g	11g	12g	30g
Min. target diameter		18mm	18mm	36mm	27mm
Material (sensor housing)		stainless steel and plastic	stainless steel and plastic	stainless steel and plastic	stainless steel and plast

FSO = full scale output

#### EC-X sensor cable 1/3/6/9 m<sup>6)</sup>



### Cable

Cable design coaxial

Sheath material FKM

Temperature stability -20°C ... +200°C

Outer diameter 3.6mm ±0.2mm

Bending radius static: ≥ 18mm
dynamic: ≥ 36mm

Suitable for use with robots no

## Plug model

Type Locking method Protection class Temperature stability Material (housing)

Mechanical service life

## Controller side

socket push-pull IP68 (when connected) -20°C ... +200°C nickel- and chromeplated brass 10,000 cycles

## Sensor side

triaxial connector, type B push-pull IP68 (when connected) -20°C ... +200°C nickel- and chrome-plated brass 10,000 cycles



<sup>1)</sup> valid for operation with DT3060 controller, referred to nominal measuring range

<sup>2)</sup> relates to midrange

 $<sup>^{\</sup>rm 3)}$  RMS value of the signal noise, static (20Hz)

<sup>4)</sup> Vibration test according to IEC 60068-2-6, shock test according to IEC 60068-2-27

<sup>&</sup>lt;sup>5)</sup> Weight of sensor head: without nuts, with cable until end of crimp sleeve

 $<sup>^{6)}</sup>$  Length tolerance cable:  $+0.5m\,/\,+1.25m\,/\,+2.35m\,/\,+3.5m$