



The EM-200-02D4 Four-door Power Window System Trainer allows for the demonstration of a complete power window system using real-world components. Terminal block receptacles are provided for diagnostic test points.

Educational Advantages:

- OEM components (window motors, switches, with OEM matching wire colors).
- A lockable system fault box allowing instructors to insert from one to four faults for student diagnostic learning.
- Electrical test points are included on the trainer for circuit diagnosis.
- Can be stored in an EM-200-10 storage cabinet and/or an EM-200-09 stand.
- User manual included.
- Trainer requires an external 12VDC power supply to operate.

Main Components:

- Power window motors (4ea).
- Master and slave switches.
- Fault box with 4 faults.
- Test points for diagnosis.

Application: 2007+ GM Chevrolet Cobalt

Dimensions: 22 x 22 x 8 in (55.9 x 55.9 x 20.3 cm)

Weight: 15 lb (6.82 kg)