

WIPER & WASHER SYSTEM TRAINER



The EM-200-06 trainer allows for the demonstration of a complete wiper and washer system using real-world components. Terminal block receptacles are provided for diagnostic test points. It includes the following:

- OEM Wiper motor
- Section of wiper transmission
- Washer fluid pump
- Wiper/washer switches
- Lockable fault box with 4 faults
- Test points for diagnosis
- Linkage enclosed in a clear plastic enclosure for safety
- Requires a 12VDC power supply to operate

Educational Advantages

- Ability to visualize the operation of wiper/washer switches, wiper motor and washer pump.
- Ability to test and verify a basic wiper and washer circuit.
- Four operational faults can be inserted to promote student diagnostic troubleshooting competencies.
- Includes wiring schematics.

Application: 2009-2010 Hyundai Accent

Dimensions: 22 x 22 x 7.25 in (55.88 x 55.88 x 18.42 cm)

Weight: 21 lb (10 kg)