

μSPEED - Product Overview

Non-Contact Length & Speed Measurement Laser-Encoder µSPEED

Product Overview Q1/2020 - Version 1.0





Product Information

µSPEED gauges are capable of measuring speed and length without contact to the moving material surface. The µSPEED Laser-Encoder systems replace tactile measurement solutions as e.g. contact wheels, which tend to measurement errors caused by slippage, chatter, dirt build-up and day to day wear problems. The maintenance free and long term calibrated µSPEED gauges measure nearly all surfaces without parameter setting.

Most important system features:

- material independent
- long term calbrated
- 0 m/s up to 100 m/s
- bidirectional measurement
- typ. accuracy better ±0,5 m at 1 km
- accredited calibratable acc. MID 2014/32/EU

Benefits

compared to tactile measurement systems:

- self-monitoring
- non-contact, no slippage
- maintenance free and permanently calibrated
- measurement independent from material, surface structur, thickness, elasticity
- can not damage material surface
- high accuracy, high repeatability

compared to other non-contact devices:

- the most compact gauge in class
- the most easy to handle gauge (plug & play)
- non-contact direction detection
- non-contact zero speed measurement
- no parameter setting necessary
- permanently calibrated
- long laser lifetime
- optimum price performance ratio
- accredited calibratable acc. MID 2014/32/EU
- Made in Germany














Calibrated Length

Application Overview

There are many different applications for the use of non-contact laser encoders:

Roll / Spool Length / Cut-to-Length Control:

- Web, rolled and spooled materials, coils
- Textile, fabrics, carpet, nonwoven, felt
- Foil, film, tape, membranes, artificial leather, Roof foil, bitumen web, geo textile
- Printed and coated material
- Paper, corrugated paper, abrasive paper, packaging material
- Rubber, laminate, extrusion material
- Tube, hose, profile, bar
- Wire, cable, rope

Discrete Part Length Measurement:

- Plate, panel, tube, bar, profile, rail
- Gypsum board, chip board, MDF panel
- Insulating panel, insulating board
- Wooden beam, panel, KVH structural timber
- Metal- and plastic tube
- Metal sheet and metal panel, slab

Counter / Encoder Calibration:

- Calibration of machine counters
- Calibration of tachometers
- Portable calibration of several production lines

Print Control:

- Printing of length scales
- Printing proportional to length

Pattern Repeat Mark Measurement:

- Packaging film, wall paper, carpet
- Measurement of print pattern distances
- Setting of printing machines

Difference Length / Speed Measurement:

- Speed balancing e.g. for lamination or coating
- Elongation speed ratio measurement
- Slippage detection (Cause study for surface errors, material and web breaks, detection of errors caused by wear and tear)

Portable Measurement



Application Examples

µSPEED gauges are designed for all kinds of conveying processes, for frequent material starts and stops as well as for changes of material feeding direction.

µSPEED gauges

- work on almost any moving objects, such as
 Web and coiled material, tube, pipe, rod, sheet,
 plate, cylinder, roller, profile, wire, cable,
 yarn, rope
- are suitable for a wide range of applications e.g Continuous length measurement,
 Cut-to-length control, Portable tachometer
 Calibration and differential speed
 measurement, Discrete part length
 measurement, Control of scale print marks
- can be found in various industrial sectors:
 Textile: fabrics, non-woven, felt and leather Plastics: film, foil and self adhesive tape, rubber, profile
 Metal: sheet, web, foil, profile, tube
 Reel goods: wire, cable, rope, fibre, yarn
 Paper: print and packaging paper, corrugated products and cardboard
 Hygenie and food as well as wood, glass and Ceramics and construction industry
 Machine building: converting industry




















Fig.: Laser-Encoder - Measurement Principle



Measurement Principle

μSPEED gauges operate according to the differential doppler method. Therefore two laser beams intersect at an angle ϕ to the optical axis on the surface of the measurement object. For a point P which moves with the velocity v through the point of intersection of the two laser beams, the frequencies of the two laser beams are doppler shifted.

The two laser beams are superimposed in the measurement volume, producing an interference pattern of light and dark stripes. The stripe spacing Δs is a constant which depends on the laser wavelength λ and the angle between the measurement beams 2ϕ :

$$\Delta s = \lambda/(2 \sin \varphi)$$

If a particle moves through the stripe pattern, the back-scattered light from the particle is modulated in its intensity. A photodetector in the sensor produces a signal whose frequency fD is directly proportional to the speed component of the surface in the measuring direction vp and:

$$fD = vp/\Delta s = (2v/\lambda) \sin \varphi$$

fD = Doppler frequency

vp = Velocity vector in measuring direction

 Δs = Stipe spacing in the measurement volume

The value of $\lambda/\text{sin}\phi$ is the measuring scale for speed and length measurement.

Figures on page 4:

Example applications of non-contact length and speed measurement: Foil, timber, textile, cable, wire, steel rope, artificial leather, measurement of cylinder speeds



Product Overview

µSPEED-SMART

- High accuracy smartsensor (typ. better ± 0,05 %)
- Mid price category
- For standard rolling/ cutting processes
- Easy electrical and mechanical integration
- Calibratable length gauge acc. MID 2014/32/EU

µSPEED-ECO

Identical to $\mu SPEED-SMART$ (see above) apart from:

- Mid accuracy (better ± 0,3 %)
- Low price category

µSPEED-PRO

Identical to µSPEED-SMART (see above) apart from:

- Non-contact bi-directional measurement
- Zero speed measurement
- For each kind of process including stop and go and direction changes
- Calibratable length gauge acc. MID 2014/32/EU

MID-COUNTER & CONTROLLER

- Display and operator unit and controller
- Control functions for cut-to-length; good/waste length counting; internal memory; direct printout control; measurement data logging
- For fix integration into machine or portable use
- For each kind of process including stop and go and direction changes
- MID-COUNTER for calibrated length measurement acc. to MID/2014/32/EU

Accessories

- Equipment for portable use: tripod, fast installation devices, case
- PC software for configuration and monitoring
- Eifferential speed measurement software
- Display-units, counters and operator interfaces
- Accessories for accredited version acc. MID 2014/32/EU e.g. printer
- Protective housings, air and water conditioning



Fig. 1: μSPEED-SMART/-ECO/-PRO



Fig. 2: MID-COUNTER & µSPEED-CONTROLLER




Fig. 3: PC-Software



Fig. 4: Big Display



Fig. 5: Tripod, Transportation Case



Specifications


		μSPEED-PRO	μSPEED-SMART & SMART-ECO	μSPEED-CONTROLLER & MID-COUNTER
Parameter	Unit			
Direction Detection		YES non-contact	via external direction signal	acc. to type of gauge
Zero Speed Measurement		YES non-contact	NO	acc. to type of gauge
Material Presence		YES non-contact	optional non-contact	acc. to type of gauge
Accuracy (typical) (2σ;L>10m/3σ;L>20m)	%	± 0,05	SMART ± 0,05 SMART-ECO ± 0,3	acc. to type of gauge
Repeatability	%	± 0,02 (except SMART-		
Gauge / Device Type		Smart Sensor	Smart Sensor	Controller + Display
Speed-Range	m/min m/s	0 to ± 1.200 0-20	1 to ± 6.000 0,02-100	acc. to type of gauge
Stand-off Distances (Tolerances)	mm	115±5 (±20)	120±5 (±20) 240±10 (±40)	
Interfaces		1 x RS-485 or RS-232 alternativ to I/Os: RS-422, RS-485		RS-232 Sensor, USB Ethernet,
I/Os	pls/m	Quadrature Output 1 to 100.000 (depending on max. speed) Input: Start, Gate, Direction, Laser Interlock Output: Status		Quadr.Out/Imp.Out RS-485 / RS-232 L-Reset, Direction, Gate Status
I/O Type		RS-422 level Laser Interlock (single, 2	24V)	4 x digital high speed I/O 5V or 24V level
Data available		Speed, Length, Signal Q Valid, Measurements, Ma	ck,	
Fieldbus		Profibus, Ethernet-IP, Profinet (fieldbus optional)		MID-CNT: Available Protocols: SOAP, XML, JSON, UPD
IP Code		Sensor head: IP67		CONTR. & MID-CNT.: Front: IP51; Back: IP20
Dimensions (LxWxH)	mm	Sensor head: 154x94x39		CONTR:236x166x126 mm MID-CNT: 96x96x160 mm
Voltage		24VDC (18 V to 30 V)		CONTR: 110-230VAC MID-CNT: 24VDC
Weight	kg	Sensor head: 1 kg		Controller: 2,5 kg MID-CNT: 1 kg
Laser Data		25mW, 780 nm (Laser class 3B)		
Ambient temperature		5 bis 55°C (41 to 131°F) non condensing		
Humindity		Cooling/heating require	d outside this range	

Specifications are subject to change without notice.



Dimensions

Fig.: Sensor head identical measured for all types of sensors_ (µSPEED-SMART, -ECO, -PRO)







ELOVIS GmbH Vincenz-Prießnitz-Str. 1 76131 Karlsruhe Germany

Tel.: +49 (0)721 933823 0 Fax: +49 (0)721 933823 23

info@elovis.de www.elovis.com